

Box contents

- ·the stroller frame
- ·the carrier
- •2 front wheels
- ·2 rear wheels



1. Unfolding carrier

- •Fold the metal frame bars outward and secure them in the plastic clips on the bottom of the carrier.
- •Push the velcro under the frame bar and attach the velcro. Repeat on the other side.
- •Place the pad in the carrier and make sure the fastening lines are on top of the pad.



2. Wheels

- •Attach the front wheels on both sides of the frame.
- •To remove the front wheels, press the metal tab and pull the wheel.
- •Push the rear wheels onto the frame. Make sure the brakes point backwards and the pins fall into place.
- •Push in those pins to remove the wheels from the axle.



3. Unfolding frame

- ·Undo the clasp on the side.
- ·Lift the handlebar of the stroller.
- •Press the button on the handlebar to extend the last part of the handlebar.



4. Placing carrier

- •The bottom of the carrier has guiderails.
- •Slide the carrier onto the frame until you hear a click or the latch locks into place.
- •To remove the carrier push the latch down while sliding the carrier off the frame.



5. Folding frame

- •Simply press the button on top of the handlebar and push down.
- •The frame will fold and the clasp on the side will lock automatically.



6. Placing in car

- •Place the carrier on the car seat with the seat belt latch facing forward.
- •Wrap the seat belt around the front of the carrier and lock the seat belt.
- •Place the seat belt under the latches and secure them.



Caution

- This carrier is for pets only.
- Max. capacity 12kg.
- ·Use the fastening lines at all times.
- •Do not use when nuts or screws are loosening.
- •Clean fabric with mild household soap and water.
- If wheel squeaks or rotates with difficulty, apply grease (like vaseline).
- ·Read warranty terms on innopet.nl



Contact customer service: +31 (0) 85 079 60 12 support@innopet.nl https://innopet.nl/en/contact Scan the QR code for detailed video instructions for your InnoPet stroller or visit innopet.nl