

Box contents

- the stroller frame
- 1 front wheel set
- 2 rear wheels
- 1 rear axle
- ·1 bag with plastic rings, pins and hubcaps
- 1 cup holder



1. Unfolding

•Undo the clasp on the side of the stroller. •Lift the stroller by the push bar to unfold



2. Rear wheels

•Put the wheel on the rear axle. •Then push one of the rings onto

- the axle and secure it with one of the metal pins.
- ·Cover all this with one of the plastic hubcaps.
- •Repeat on the other side. •Push the rear axle with the rear wheels onto the frame of the stroller.



5. Uninstall rear wheels

•With a retractable ballpoint pen, push in the pins on the frame near the rear axle to remove the axle. •Push the hubcap up with your fingers or a flat screwdriver. •Now pull out the metal pin to

remove the wheel from the axle.

Tip 1

If rings, pins and hubcaps remain. these are spare parts. Store these carefully.



Tip 2

The front wheel can rotate 360 degrees. To prevent the wheel from turning, fixate it by pushing the clip on the front wheel upwards.



Tip 3

Take the cup holder and push it over the bars of the frame until the screws fall into the holes of the



3. Front wheel

 Put the front wheel on the frame. you will hear a click when it is secured.

•To remove the front wheel, you will need pliers. Using the pliers, push in the latch and pull the wheel off the frame.



4. Folding

•Make sure the cabin is unzipped and the front wheel is not locked. Slide the top of the folding mechanism to the left and push in the button on the handlebar. •Turn the handlebar away from you. •Fasten the clasp on the side to prevent unfolding during transport.



cup holder.

Caution A

- •This carrier is for pets only.
- ·Max. capacity 20kg.
- ·Use the fastening lines at all times.
- ·Fully unzip the cabin before folding.
- ·Do not use when nuts or screws are loosenina.
- ·Clean fabric with mild household soap and water.
- ·If wheel squeaks or rotates with difficulty, apply grease (like vaseline).
- ·Read warranty terms on innopet.nl

Allure Instruction manual

Contact customer service: +31 (0) 85 079 60 12 support@innopet.nl https://innopet.nl/en/contact Scan the QR code for detailed video instructions for your InnoPet stroller or visit innopet.nl

