

#### **Box** contents

- •the stroller frame 2 front wheels
- 2 rear wheels
- 1 rear axle
- 1 rain cover



## 1. Unfolding

•Before unfolding, push the rear axle on the frame of the stroller. •Undo the clasp on the side of the stroller

•Lift the stroller by the push bar to unfold.



#### 2. Rear wheels

•Push the rear wheel onto the rear axle while pressing the button on the wheel.

•Press in the same button to remove the wheels from the axle. •To remove the axle, use a retractable ballpoint pen and push in the pins on the frame.

## Tip 1

To apply the brake on the stroller, step with one foot on the step panel of the brake bar.

#### Tip 2 The front wheels

from turning, fix it



#### 3. Front wheel

 Put the front wheel on the frame. you will hear a click when it is secured. Repeat on the other side. •To remove the front wheels, you will need pliers. Push in the latch and pull the wheel off the frame. Repeat on the other side.



4. Fastening cover

•Make sure the fabric cover is always correctly attached to the frame.

•At the back of the stroller, pull the fabric over the bar of the frame. attach the velcro and zip up the cover.



#### **5.** Foldina

•Make sure the cabin is unzipped. ·Slide the top of the handlebar to the left and push in the button on the handlebar. Push the bar down to fold the stroller.

•Fasten the clasp on the side of the stroller to prevent unfolding during transport.

upwards.

by pushing the clip

on the front wheel

can rotate 360

degrees. To pre-

vent the wheels



# Tip 3

When unfolding, be sure to release the clasp on the side. Otherwise you will not be able to unfold the stroller.

# Caution A

•This carrier is for pets only.

- •Max. capacity 50kg
- ·Use the fastening lines at all times.
- •Fully unzip the cabin before folding.
- ·Do not use when nuts or screws are loosening.
- ·Clean fabric with mild household soap and water
- ·If wheel squeaks or rotates with difficulty, apply grease (like vaseline).
- ·Read warranty terms on innopet.nl

# ImmoPet Manut Instruction manual

Contact customer service: +31 (0) 85 079 60 12 support@innopet.nl https://innopet.nl/en/contact Scan the QR code for detailed video instructions for your InnoPet stroller or visit innopet.nl

